




SINGER
337

List of Parts—Machine No. 337



List of Parts—Machine No. 337



94167-012
081563 000, 92964-012
FOR ALTERNATIVE VOLTAGES
SEE PARTS LIST SECTION

