


**SINGER**  
631








# List of Parts-SINGER 631




## ATTACHMENT SET 503664

81200	Binder
161166	Zipper Foot
161167	Applique Foot
161168	Button Foot
161172	Seam Guide
161195	Hemmer Foot
161276	Lint Brush
161294	Screwdriver (IG)
161295	Screwdriver (SH)
161307	Threader Wire
161561	Ruffler
161596	Darn. and Emb. Foot
161609	Tube of Oil
170071-001	Presser Foot
172187	Fashion Disc 2
172189	Fashion Disc 3
172191	Fashion Disc 5
172229	Fashion Disc 4
172336	Bobbin (Plastic) (4)
507112	Throat Plate
507114	Feed Cover Plate
507115	Throat Plate
507140	Spool Pin Lead-Off
507153	Spool Pin
507182	Loop Retaining Insert
2020(15x1)	Needles 11 (3) 14 (3)




# List of Parts - SINGER 631




# List of Parts-SINGER 631



# List of Parts - SINGER 631



## Electrical Parts



## Attachment Set No. 503 664

